

Prevent accidental drive offs

FUEL CAP ISOLATION SYSTEM

MUIRHEAD®
PROTECTION SYSTEMS

The Muirhead® Fuel Cap Isolation system has been designed to prevent the machine operator from starting the machine and driving away with the fuel filler still attached. This will eliminate damage to machines, refuelling stations, hoses and prevent hazardous fuel spills.

The system inhibits the operator from starting the machine, without firstly ensuring the fuel cap has been placed securely back onto the quick fill adaptor on the fuel tank.

The Muirhead® Fuel Cap Isolation system has an intrinsically safe circuit design with safety certification (inductive sensor) for the fuel cap component to be fitted in a zone 0 hazardous area.



FEATURES

- Intrinsically safe circuit design
- High quality connectors and wiring components
- Water and vibration resistant
- Safety certificate for the fuel cap (inductive sensor) to be used in a zone 0 hazardous area
- Prevents damage to the refuelling station
- Reduces refuelling accidents
- Reduces contaminants entering tank
- Maintenance free operation
- Easy to install
- In dash visual indication



Part No. 7811 | Fuel cap isolation system

Part No. 8900 | Optional 12-24 volt regulator

RCT Distributor and Service Provider

WESTERN SUBURBS
Auto Electrics

Unit 7/29 Collinsvale St
Rocklea Qld 4106 ABN 87 169 228 602
Ph: 07 3272 7511 Fax: 07 3272 7533
Mob: 0417 781261 email: info@wsae.com.au
Web: www.wsae.com.au

Refer: SBMH0909073

Manufactured or distributed by RCT. Copyright© Remote Control Technologies Pty Ltd